



# MesaLabs

## **Mesa Torqo Model 1600 How to Configure Data Sample Replace and Delete Options June 19, 2013 Page 1 of 2**

### **I. Overview**

Torqo Model 1600 Firmware with version 5.09 and later allows administrators to configure several data sample edit and deletion options. By default, individual data samples may be replaced with newer samples, individual data samples may be deleted, and all data samples for a specific profile may be deleted. In some instances this capability is not desirable. We have added some configuration settings to allow these data sample functions to be disabled by the user.

Please note: these instructions assume some familiarity with Windows XP operating systems including opening files and folders.

### **II. Procedure**

1. Obtain and install the Torqo Model 1600 Firmware upgrade with version 5.09 or higher.
2. After the upgrade is completed, run the Torqo Model 1600 Firmware by double clicking the Torqo icon on the Torqo touchpanel desktop. This will create the default settings for configuring the Delete Sample, Replace Sample and Delete All buttons. The default settings are all three buttons are enabled.
3. Exit from the Torqo application from the Main Menu select Exit to Windows and click OK.
4. Bring up the on-screen keyboard by touching Start, All Programs, Accessories, Accessibility, On-Screen Keyboard.
5. Touch the Start button on the lower left corner of the Windows desktop.
6. Select My Computer, then under Hard Drives select Local Disk D:
7. Open the Torqo folder then open the SYSTEM folder.
8. Double click the file mesa.txt to open it in the notepad file editor.
9. You will see the default selections for the button configuration at the bottom of the file. Default settings are:  
SINGLE SAMPLE DELETE = ENABLE  
ALL SAMPLE DELETE = ENABLE  
SAMPLE REPLACE = ENABLE
10. Make the changes to enable and disable the desired buttons:  
SINGLE SAMPLE DELETE = DISABLE  
ALL SAMPLE DELETE = ENABLE  
SAMPLE REPLACE = DISABLE



# MesaLabs

## Mesa Torqo Model 1600 How to Configure Data Sample Replace and Delete

### Options

June 19, 2013 Page 2 of 2

11. Select File, Save then exit the notepad editor.
12. Close the browser window.
13. Start the Torqo application by double clicking the Torqo icon on the Torqo touchpanel desktop.
14. Test the settings to confirm your selections. Choose a Profile and click View/Print then Delete Data.
15. Buttons selected as DISABLED will be gray and will not respond to touches. Please note: if all three buttons are disabled a warning message is shown when the Delete Data button is touched.